

Multi Spectral Camera System Resource File

Multi Camera Synchronous Image & GPS Location, Attitude Capturing System

Author: Prashant Kumar

pkv@vt.edu

MS student at Unmanned Systems Lab, VT

Date 3rd August 2018

General Information about System:

Cam1: UI-3241LE-M-GL: monochrome camera; Narrow Blue Bandpass Filter 470 nm

Cam2: UI-3241LE-C-HQ: color camera; No filter

Cam3: UI-3241LE-M-GL: monochrome camera; Dark Red Bandpass Filter 660 nm

Cam4: UI-3241LE-M-GL: monochrome camera; Narrow Green Bandpass Filter 532 nm


Cam5: UI-3241LE-NIR-GL: monochrome NIR camera; NIR Bandpass Filter 850 nm

Cam6: UI-3241LE-NIR-GL: monochrome NIR camera; Bandpass Filter 970 nm


On-board computer password: usl

Terminal can be opened using 'Right Mouse Click -> Open in Terminal' in a folder or on desktop.


Program saves images in folder '/mnt/dr1/images'. For every run it creates a new folder with name consisting of date and time combination, e.g., '2018-08-03-23-30-40' meaning 3rd Aug 2018 at 23:30:40:



Inside the folder it arranges Camera Images and files like gps log, experiment notes and program running log in the following fashion:



Cameras can be checked by running the program 'idscameramanager' on a terminal. It would open the following:



Cameras can be opened by double clicking the specific cameras. This can be used to focus cameras whenever required. The camera id's represent the physical camera numbers. Do not change the camera id's. To focus the cameras, open one camera, e.g., camera id 2, which is color camera, by double clicking it in the camera manager. Direct the camera to an object which is at a distance at which you want to focus it. If the object appears sharp in the camera output, the camera is focused, otherwise rotate the lens slowly in either directions to attain focus. Do this for all cameras. Close the program after completing this procedure. The camera focus needs to be checked for all cameras whenever they are used after a long time or if the camera focus might have been disturbed.

Running the program will look like this on a terminal:

```
prashant@udoo: /mnt/dr1/Program
prashant@udoo:/mnt/dr1/Program$ sudo ./mcs

**** Multi Spectral Camera Image Capture Program ****

Important notes:
1. If cameras do not initialize then either remove camera USBs for 5 seconds or shutdown computer, disconnect power, reconnect power and restart computer.
2. Folder '/mnt/dr1/images' should exist. Additional folder with current date time will be created and all images will be saved in it.
3. To print everything use the command line: './mcs --log' (not recommended).
4. To use single camera, use './mcs --cam n', n being camera number 1-6.
5. To stop program, press 'Esc' key and press Enter.
6. Provide notes at start and end of program when asked for your future reference. Notes will be saved in file notes.txt
7. To not use mavlink use './mcs --no_mavlink'.

Created save directory: /mnt/dr1/images/2018-08-03-23-30-40/
Camera IDs: Usage:
1 true 2 true 3 true 4 true 5 true 6 true

Setup cameras:
_settingUpCamID_1_1_cam1 params set. success
_settingUpCamID_2_2_cam2 params set. success
_settingUpCamID_3_3_cam3 params set. success
_settingUpCamID_4_4_cam4 params set. success
_settingUpCamID_5_5_cam5 params set. success
_settingUpCamID_6_6_cam6 params set. success

All Camera Setup Result: success

Enter start comments for this imaging session:
This experiment is in front of USL lab to test the system.
Start serial port
Initialize MAVLINK
OPEN PORT
Connected to /dev/ttyUSB0 with 115200 baud, 8 data bits, no parity, 1 stop bit (8N1)

Start api
START READ THREAD

CHECK FOR MESSAGES
Found

GOT VEHICLE SYSTEM ID: 1
GOT AUTOPILOT COMPONENT ID: 1

INITIAL POSITION XYZ = [ -146.7904 , -155.6397 , -8.6991 ]
INITIAL POSITION YAW = -2.3153

START WRITE THREAD

MAVLINK initialized

Start capturing...

    ImgNo_0___Cam1___Cam2___Cam3___Cam4___Cam5___Cam6___
696ms  ImgNo_1___Cam1___Cam2___Cam3___Cam4___Cam5___Cam6___
994ms  ImgNo_2___Cam1___Cam2___Cam3___Cam4___Cam5___Cam6___
1002ms ImgNo_3___Cam1___Cam2___Cam3___Cam4___Cam5___Cam6___
1003ms ImgNo_4___Cam1___Cam2___Cam3___Cam4___Cam5___Cam6___
```

It shows cycle time at the left side after capturing starts.

It asks you for comments/notes about the experiment at the start and end of the program for your future reference.

Closing the program (by pressing Esc key and then Enter key) will look like this on the terminal:

```
prashant@udoo: /mnt/dr1/Program
989ms  ImgNo_115  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1007ms ImgNo_116  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
991ms  ImgNo_117  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1007ms ImgNo_118  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
993ms  ImgNo_119  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1008ms ImgNo_120  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
985ms  ImgNo_121  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1006ms ImgNo_122  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
998ms  ImgNo_123  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1011ms ImgNo_124  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
994ms  ImgNo_125  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1006ms ImgNo_126  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
994ms  ImgNo_127  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1000ms ImgNo_128  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
989ms  ImgNo_129  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1011ms ImgNo_130  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
983ms  ImgNo_131  Cam1
26ms   ImgNo_132  Cam2 Cam3 Cam4 Cam5 Cam6
989ms  ImgNo_133  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1004ms ImgNo_134  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
994ms  ImgNo_135  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
986ms  ImgNo_136  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1010ms ImgNo_137  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1006ms ImgNo_138  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
997ms  ImgNo_139  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
985ms  ImgNo_140  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1012ms ImgNo_141  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
998ms  ImgNo_142  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1000ms ImgNo_143  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1000ms ImgNo_144  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
999ms  ImgNo_145  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
993ms  ImgNo_146  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1006ms ImgNo_147  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
999ms  ImgNo_148  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
990ms  ImgNo_149  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
1014ms ImgNo_150  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
^[996ms ImgNo_151  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6

997ms  ImgNo_152  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6
Esc key pressed..

1005ms ImgNo_153  Cam1 Cam2 Cam3 Cam4 Cam5 Cam6_CLOSE THREADS


CLOSE PORT

Exit camera: 1... Exited.
Exit camera: 2... Exited.
Exit camera: 3... Exited.
Exit camera: 4... Exited.
Exit camera: 5... Exited.
Exit camera: 6... Exited.

Enter end comments for this imaging session:
This was a good experiment.


Everything saved at location:
/mnt/dr1/images/2018-08-03-23-30-40/
prashant@udoo: /mnt/dr1/Program$
```

GPS log file is created with the following details about location and attitude for every image number:




This file can be opened in MS Excel and Text to Columns functionality can be used to make data columnar.

Notes file is saved the following way:




A log file is also created for tracing bugs during program crashes.

Pixhawk has been set with the following parameters:




Steps to run Program:

1. Open the 250Gb external hard disk folder named 'dr1' shown as the last icon on the taskbar:



2. Go to folder named 'Program':



3. Open a terminal here by right clicking inside the folder and selecting 'Open in Terminal'.

Use the following commands on terminal to check if pixhawk is actually sending mavlink data:

```
sudo -s
```

It will ask for password which is 'usl' as mentioned above. Terminal will change from prashant@udoo~\$ to root@udoo~\$. Now enter the following command:

```
gtkterm
```


A new blank window with menu items will open. In its menu, go to 'Configuration' and click 'Ports'. Select port 'USB0' at the bottom of dropdown list and baud rate as '115200' also at the bottom of the dropdown. After saving these configuration settings, in the window unreadable data will start showing up. If yes, then mavlink GPS data is being received by the computer. If not then mavlink GPS data is not being received by the computer. Check if the pixhawk is turned on and FTDI cable is correctly connected. After checking data being received and confirming the port, close the gtkterm window. In the terminal write the following command

`'exit'`

Terminal will change back to `prashant@udoo~$`.

This step of checking gtkterm does not need to be performed all the time. If GPS is in lock and sending data, then this does not need to be checked.

4. Run the program by entering the following command in the terminal window:
`sudo ./mcs`

It will ask you to enter some notes for the experiment. This is for your future reference.

5. Program can be stopped by pressing the 'Esc' key and then 'Enter' key. It will again ask you to enter notes for the experiment for your future reference. You can enter here if the experiment proceeded as you planned or not. Lastly it gives the location of where everything of the experiment was saved.

NOTE: If for some reason the camera crashes, then computer needs to be shut down, its power disconnected, wait 5 seconds, reconnect power and the process needs to be followed again.